

SONY

Memory Card Recorder
Quick Start Guide



ICD-LX30

4-292-516-61 (1)

© 2011 Sony Corporation Printed in China



Welcome to your new Sony memory card recorder!

This is the Quick Start Guide, which provides you with instructions on the basic operations of the memory card recorder.

Please read it carefully. We hope you enjoy using your new Sony memory card recorder.

Please refer to the operating instructions stored on the supplied SD memory card for details of functions.


Checking the contents of the package

- Memory card recorder (1)
- AC adaptor (1)
- LR03 (size AAA) alkaline batteries (2)
- Hand Strap (1)
The strap is attached via the strap hole of the memory card recorder.
- SD memory card (2GB) (1)
- Carrying pouch (1)
- Operating Instructions (Stored in the supplied SD memory card)
- Quick Start Guide (1)

When you format the supplied SD memory card, the operating instructions stored in the supplied SD memory card will also be erased. To get another copy of the operating instructions, please visit the Sony support home page: <http://www.sony-asia.com/support>


Getting Started

1 Insert two batteries.



- 1 Slide and lift the battery compartment lid.
- 2 Insert LR03 (size AAA) alkaline batteries with correct polarity, and close the lid.

2 Insert the supplied SD memory card.




- 1 Open the cover of the memory card slot.
- 2 Insert a memory card securely to the end of the slot until it clicks into place.
- 3 Close the cover of the memory card slot.

Note

The memory card recorder does not have an internal memory. Be sure to insert the memory card before recording.

3 Slide the HOLD-POWER switch in the direction of "POWER" and keep it there to turn on the memory card recorder.




Hint

The HOLD-POWER switch returns to the center position automatically when you release it.


4 Press ◀ or ▶ to select "是," then press ▶ to set the clock settings.

The clock setting screen appears.



5 Set the year, month, day, hour, and minute in sequence using ◀ or ▶ and ▶.

When you set the minute, the "设置完成" message is displayed.



Hint


You can return to the previous window by pressing MENU if you make a mistake in the clock settings.

Let's use the memory card recorder

This section explains how to play back the test recording file immediately. The recorded files are not erased if you record the next file within few seconds.


1 Press ○ to start recording.

The ○ button is lighting up and the memory card recorder enters the recording mode.



2 Press □ to stop recording.


"请稍候" appears in the display window, then the recording stops.



The status of the memory card recorder
The number of the recorded file (in the sequence of files that were recorded on the same day)/Displays the total number of files that were recorded on the same date

3 Press ▶ to play back.


The test recording starts playing back.



4 Press □ to stop the playback.

The test recording stops.

Turning the power off




Slide the HOLD-POWER switch in the direction of "POWER" and keep it there until "关机" animation appears. The memory card recorder will turn off in a few seconds.

Hint


When you are not going to use the memory card recorder for a long time, we recommend to turn off the memory card recorder. When the memory card recorder is in the stop mode, and you leave the memory card recorder without attempting an operation for approx. 30 minutes, the auto power off function will take effect.

About memory card access indicator



The memory card access indicator is flashing in orange when the memory card recorder is accessing the memory card. Do not remove the SD memory card, batteries, or disconnect the AC adaptor while the memory card access indicator is flashing.

To set the beep sound to OFF




Press MENU to enter the menu mode. Press ◀ or ▶ to select "提示音" then press ○. Press ◀ or ▶ to select "关," then press ○.


Searching the recorded files

1 Press SEARCH.

The date selection screen appears.




2 Press ◀ or ▶ to select the date when you recorded the desired file, then press ▶.



3 Press ◀ or ▶ to select a file.


Press ▶ to select a more recent file.
Press ◀ to select an earlier file.




Playing back the searched file

1 Press ▶ to start playing back.

The selected file starts playing back.




2 Press VOL +/- to adjust the volume.



3 Press ◻ to stop the playback.


The selected file stops.




Erasing the searched file

1 Press ERASE.

"确定删除?" appears and the specified file is played back for confirmation.




2 Press ◀ or ▶ to select "是."



3 Press ▶.

The "正在删除..." animation appears in the display window and the selected file will be erased.



Hint

When a file is erased, the remaining files will advance so that there will be no space between files.

Capacity of the supplied SD memory card with the memory card recorder (User available capacity)

2 GB (approx. 1.80 GB = 1,932,734,976 Byte)

A part of the memory capacity is used as a management area.